

Installation in 6 steps

Wispero 3D wall panels · one afternoon, no drilling, no dust

1

Plan the layout

Lay the panels out on the floor or tape paper templates to the wall with masking tape. Take a photo and adjust the layout.



2

Prepare the wall

The wall must be clean, dry and sound, with no flaking paint. Mark a guide line in pencil (use a spirit level).



3

Glue the panels

Apply mounting adhesive (e.g. hybrid MS polymer) in dots or strips to the back of the panel and press firmly. On the ceiling, hold with tape until dry.



4

Fill the gaps

Fill the joint between panel and wall with acrylic caulk – the panel will blend into the wall.



5

Paint

Use wall paint: a short-pile roller and a brush for the edges. Two thin coats.



6

Add an accent

A panel in a different colour or a gloss finish is easiest to paint before gluing.

